




ITEM NO: I3017-370C Corner Desk

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.

WARNING! Before using this product, please read, understand, and follow these instructions. Failure to follow each of these assembly instructions precisely may result in damage to the product and / or injury to the consumer.












UNIT SHOULD BE INSTALLED BY 2 OR MORE PERSONS.








TOOLS REQUIRED (NOT PROVIDED)

PHILLIPS SCREWDRIVER 


COMPONENTS LIST:

No.	Description	Sketch	Quantity
1	Desk Top		1 PC
2	Front Left Leg		1 PC
3	Rear Left Leg		1 PC
4	Front Right Leg		1 PC
5	Rear Right Leg		1 PC
6	Corner Leg		1 PC
7	Removable Triangle Top		1 PC
8	Long Stretcher		2 PCS
9	Short Stretcher		2 PCS

HARDWARE LIST:

No.	Description	Sketch	Quantity
A	Bolt Ø5/16" x 1-1/2"		10 PCS
B	Lock Washer Ø5/16"		10 PCS
C	Flat Washer Ø5/16" x 3/4"		10 PCS
D	Allen Wrench M4		1 PC
E	Wood Screw #4 x 1-1/2"		8 PCS

FUNCTIONALITY INSTRUCTION




FOR INDOOR USE ONLY



ITEM NO: I3017-370C Corner Desk


STEP 1: Put the desk top face down on a soft surface.

STEP 2: Completely pull out the side drawers. Attach all legs to the desk top by using 10 bolts (A), lock washers (B) and flat washers (C). Do not completely tighten bolts.



STEP 3: Attach both long stretchers and short stretchers to the legs with 8 wood screws (E). Completely tighten all bolts and wood screws. Push back the side drawers.

STEP 4: Turn the assembled desk to the upright position.



STEP 5: Place the Removable Triangle Top on desk top as shown below.

