




ITEM NO: I631-6600S Upholstered Dining Chair (2/Ctn)

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may come loose inside the carton during shipment.



TOOLS REQUIRED (NOT PROVIDED)

PHILLIPS SCREWDRIVER


HARDWARE LIST:

No.	Description	Sketch	Quantity
A	Bolt Ø5/16" x 2"		8 PCS
B	Lock Washer Ø5/16"		8 PCS
C	Flat Washer Ø5/16" x 3/4"		8 PCS
D	Allen Wrench 4mm		1 PC

COMPONENTS LIST:

No.	Description	Sketch	Quantity
1	Chair Seat		1 PC
2	Front Leg		2 PCS
3	Back Leg		2 PCS

FUNCTIONALITY INSTRUCTION



BEFORE USING THIS PRODUCT PLEASE READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS.

Save these instructions for future reference.

FOR INDOOR USE ONLY



ITEM NO: I631-6600S Upholstered Dining Chair (2/Ctn)

STEP 1: Attach the front legs and back legs to chair seat by using 8 bolts (A), lock washers (B) and flat washers (C) with an allen wrenches (D) as shown below. Completely tighten all bolts. Turn the assembled chair to the upright position.

